

Simultaneous application of roll control and thrust reduction may be necessary.

The pilot should also extend the speed brakes as necessary.

Summary

- These techniques assume that the airplane is not stalled. If it is, recovery from the stall must be accomplished first.
- It is possible to consolidate and incorporate recovery techniques into the two basic scenarios of nose high and nose low.