

Nose Low

Pilot-Flying	Pilot-Not-Flying
Recognize and confirm the situation.	
 Roll in the shortest direction to wings level (unload and roll if bank angle is more than 90 degrees). Reduce thrust. Recover to level flight: Apply nose-up elevator. Apply nose-up trim, if required. Adjust thrust and drag, as required. 	 Call out attitude, airspeed, and altitude throughout the recovery. Verify all required actions have been completed and call out any omissions.

For the A300 Fleet Support Team Captain Delvin Young